



LowandMean.com
928.255.0230

YAMAHA ROAD STAR **HONEY COMB SCREENS**

Part # LM-04-100S, RS

INSTRUCTIONS

LM-04-100S, RS includes:		WARNING: Do not install with the motor warm. This is an install at your own risk. If you are not capable to install successfully then we highly suggest you take this item to a professional shop. Always check the fit before sending this product off to paint. BE VERY CAREFUL WITH THE SUPER GLUE AS IT IS THIN AND CAN RUN ON TO YOUR FINISHED SURFACE.
1	Low & Mean glue	
1	Double sided tape	

Suggestions for install:

- 1) First, Install LM-04-100,R (chin fairing) to check fit (see product instructions).
- 2) Install the Honey Comb screen to inside chin fairing by placing the chin fairing on a stable surface.
- 3) We supplied some double sided sticky tap to help hold the screen while you're super gluing. Cut the double sided sticky tape in ½" pieces and stick around the edge where the screen get's glued.
- 4) It's important to bend the screen to the shape of inside of the chin fairing.
- 5) When using the Low & Mean glue be careful not to let the glue run onto the front side of the chin fairing. Start by gluing a little at a time. If you're having trouble with the super glue dry time, then we suggest buying a bottle of Hobby Shop super glue Accelerator. (This is not something we can ship.)
- 6) Gluing Honey Comb screen completely. Check the fit to the bike an if you plan on sending the chin fairing out for paint.

Check fit and firmness after your first ride of showing off your *Nice bike™*.



Please contact our Tech support if you have any issues or questions on install
Techsupport@LowandMean.com or 928-255-0230